

# ProfilerPRO Spectro Installation Instructions

Refer to the Spectro Suite User Guide, included, for complete instructions.

## Before Installing:

- Disable any anti-virus software. After you have installed the products, you may re-enable the anti-virus software.
- Make sure that you do NOT plug the Spyder™ into the computer before software installation.
- Set your display to at least 640 x 480 resolution.
- Set your display to at least 24-bit color (True Color).
- Make sure that you are logged in as Administrator or a user with FULL Administrator privileges (where applicable).

## A note about Monitor Calibration:

The ProfilerPRO Spectro Suite, and the ProfilerPRO Spectro Suite Upgrade do not include monitor calibration. We strongly recommend you calibrate your monitor before profiling your printer. Doing so will ensure an accurate, color managed workflow.

## Step 1. Installing ProfilerPRO:

### Mac:

- a. Load ProfilerPRO CD into CD-ROM drive.
- b. Double-click ProfilerPRO Installer.
- c. Follow On-Screen Instructions.
- d. Upon successful installation, choose "Quit."

### Windows:

- a. Load ProfilerPRO CD into CD-ROM drive.
- b. Choose "Install ProfilerPRO."
- c. Follow On-Screen Instructions.
- d. Upon successful Installation, choose "Finish."

## Step 2. Connecting the ColorMouse to Your Computer:

### Mac Serial:

- a. Turn off your computer.
- b. Connect the MINI Din 8 plug on the "Y" cable to the Printer or Modem port on your computer.
- c. Connect the Power Jack to the Power Supply Plug on the "Y" cable.
- d. Connect the 8-pin Modular Connector to the jack located to the lower rear of the ColorMouseToo!
- e. Plug the Power Supply into an AC outlet.
- f. Verify operation by pressing the Measure Button and viewing light emitted from the Sensor Cone.

### Windows Serial:

- a. Turn off your computer.
- b. Connect the MINI-DIN 8 plug on the "Y" cable to the DB9 adapter. Plug the adapter into your computer's serial port.
- c. Connect the Power Jack to the Power Supply Plug on the "Y" cable.
- d. Connect the 8-pin Modular Connector to the jack located to the lower rear of the ColorMouseToo!
- e. Plug the Power Supply into an AC outlet.
- f. Verify operation by pressing the Measure Button and viewing light emitted from the Sensor Cone.

### Mac and Windows USB:

- a. Connect the USB adapter to the DB9 adapter.
- b. Connect the DB9 adapter to the MINI-DIN 8 plug on the "Y" cable.
- c. Connect the Power Jack to the Power Supply Plug on the "Y" cable.
- d. Connect the 8-pin Modular Connector to the jack located to the lower rear of the ColorMouseToo!
- e. Plug the Power Supply into an AC outlet.
- f. Plug USB plug into your computer's USB port.
- g. Verify operation by pressing the Measure Button and viewing light emitted from the Sensor Cone.

## Step 3. Installing ColorMouse : Note-Refer to the "ColorMouseToo! rev C.pdf" on the ColorSavvy CD for complete instructions.

### Mac:

- a. Load ColorSavvy CD into CD-ROM drive.
- b. Double-click "User Software" folder.
- c. Double-Click "ColorMouseTrap 1.02 Installer."
- d. Follow the On-Screen Instructions.
- e. Upon successful installation, choose "Quit."

### Windows:

- a. Load ColorSavvy CD into CD-ROM drive.
- b. Double-click "User Software" folder.
- c. Double-click "CSConnect\_1.11\_install."
- d. Follow the On-Screen instructions.
- e. Upon successful installation, choose "Quit."

### Note: USB Adapter Driver

Your USB adapter, if used, will require you to install drivers. For Macintosh, please go to: <http://www.newusb.com/usa/downloads.html>. For Windows, please go to: <http://www.newusb.com/usa/downloads.html>.